


Savage Model 99 Repeating Lever Action Rifle

Serial Number from 90,000 to 1,000,000 (If Below 90,000 Return Rifle to Factory)

COMPONENT PARTS

(When ordering parts, it is necessary to specify model number and letter, caliber or gauge, serial number if any)



Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
*99-1	Barrel Less Sights (Specify Caliber)	340C-229	Folding Rear Sight and Step	99-431	Lever Lock Pin
*99-2	Receiver	110-233	Folding Rear Sight Step	99-433	Lever Lock Tension Spring
99-5	Butt Plate	775-252	Stock Bolt	99-434	Carrier (Specify Caliber and Serial Number)
†99R-5	Butt Plate (Model R)	†99F-252	Stock Bolt (Model F)	†	Carrier Assembly No. 99-705 (Specify Caliber and Serial Number)
99-11	Barrel Stud (Solid Frame)	94-253	Stock Bolt Washer	†99H-434	Carrier (Specify Caliber and Serial Number)
99TD-11	Barrel Stud (Takedown)	530-278	Automatic Cut-off Spring (Give Serial Number)	†	Carrier Assembly No. 99H-705 (Specify Caliber and Serial Number)
†99F-11	Barrel Stud (Model 99F only)	99-279	Trigger	99-435	Carrier Spindle (Give Serial Number)
*99-25	Breech Bolt (Give Serial Number)	99-284	Trigger Spring	99H-435	Carrier Spindle (Give Serial Number)
†*	Breech Bolt Assembly (Complete) No. 99-710 (Give Serial Number)	99-285	Trigger Pin	99-436	Carrier Spindle Head
†*	Breech Bolt (Give Serial Number)	99-289	Dummy Screw Tang	99-437	Carrier Spindle Head Screw
†*	Breech Bolt Assembly (Complete) No. 99H-710 (Give Serial Number)	99R-289	Dummy Screw Telescope	99-438	Carrier Spindle Nut
99-30	Carrier Spring	99-396	Firing Pin Securing Pin	99-441	Sear Screw (Give Serial Number)
99-32	Butt Plate Screw	99-410	Automatic Cut-off (Give Serial Number)	99H-441	Sear Screw (Give Serial Number)
99-59	Extractor	99-411	Automatic Cut-off Spring (Give Serial Number)	99-442	Sear Screw Nut
99-65	Extractor Pin	99-412	Breech Bolt Stop (Give Serial Number)	99-444	Breech Bolt Stop Screw
99-75	Slot Bank	99H-412	Breech Bolt Stop (Give Serial Number)	99-444	Trigger Spring Screw
99-77	Firing Pin (Give Serial Number)	99-414	Cartridge Guide (Specify Caliber and Serial Number)	99H-576	Carrier Spindle Support (Give Serial Number)
99TD-80	Fore-end Clip	99-414	Cartridge Guide (Give Serial Number)	99-702	Lever Bushing
99TD-92	Snap Lock Block Locking Wood Screw	99H-414	Cartridge Guide (Give Serial Number)	99-703	Fore-end, Solid (Checkered) (Model E. G.)
99TD-103	Fore-end Clip Retaining Piece	99-415	Cartridge Guide Pin	†99F-703	Fore-end, Semi-Beavertail (Model R)
99TD-106	Fore-end Clip Retaining Piece Screw	*99-415	Lever	†	Fore-end, Semi-Beavertail Featherweight (Model 99F) (Specify Caliber)
99-107	Hammer	99-419	Lever Bushing Screw	†99TD-703	Fore-end Wood, Takedown Fore-end Assembly Complete Takedown No. 99TD-743
†	Hammer Assembly (Complete) No. 99-701	99-421	Fore-end Screw (Model E. G.)	99-704	Lever Lock Safety
99TD-118	Snap Lock Block Locking Bolt	99-421	Fore-end Screw (Model R or F)	99-707	Sear
99TD-137	Snap Lock Block Locking Bolt Spring	99-422	Pistol Grip Cap	99-708	Stock with Butt Plate, Pistol Grip (Model E. G. or F)
99TD-138	Snap Lock Block Machine Screw	99-423	Pistol Grip Cap Screw	†99R-708	Stock with Butt Plate, Pistol Grip (Model R)
99-166	Mainspring	99-424	Hammer Bushing	†99SG-708	Stock with Butt Plate (Straight Grip)
99TD-170	Snap Lock Block Machine Screw Nut	99-425	Hammer Bushing Screw		
99TD-181	Snap Lock Block Thumb Piece	99-426	Hammer Indicator		
99TD-183	Snap Lock Block	99-427	Hammer Indicator Pin		
†	Snap Lock Block Assembly (Complete) No. 99TD-744	99-428	Hammer Indicator Spring		
99TD-185	Barrel Stud Bushing	99-429	Hammer Retractor Spring		
99-218	Front Sight				

*Not supplied on Mail Order. Complete rifle must be shipped to factory for fitting. An additional charge will be made for disassembling, adjusting and reassembling action.
 †Parts are not illustrated.

(a) This fore-end will only fit rifles stamped Model 99F on right side of barrel.